


# Installation and operation manual

---

## Remote control

for Caldaria



## DISPOSAL

The appliance and all its accessories must be disposed of separately in accordance with the regulations in force.



Use of the WEEE symbol (Waste Electrical and Electronic Equipment) indicates that this product cannot be disposed of as household waste. Proper disposal of this product helps to prevent potential negative consequences for the environment and human health.

Revision: A

Code: D-LBR718EN

This Installation and operation manual has been drawn up and printed by Robur S.p.A.; whole or partial reproduction of this Installation and operation manual is prohibited.

The original is filed at Robur S.p.A.

Any use of this Installation and operation manual other than for personal consultation must be previously authorised by Robur S.p.A.

The rights of those who have legitimately filed the registered trademarks contained within this publication are not affected.

With the aim of continuously improving the quality of its products, Robur S.p.A. reserves the right to modify the data and contents of this Installation and operation manual without prior notice.

---

# INDEX OF CONTENTS

<b>1</b>	<b>How to use this instruction manual</b> .....	<i>p. 4</i>	<b>9</b>	<b>Setting manual/automatic operation</b> .....	<i>p. 10</i>
<b>2</b>	<b>Main features</b> .....	<i>p. 4</i>	9.1	Manual operation .....	<i>p. 10</i>
<b>3</b>	<b>Installation</b> .....	<i>p. 5</i>	9.2	Automatic operation .....	<i>p. 11</i>
<b>4</b>	<b>Configuration of the operating parameters</b> .....	<i>p. 7</i>	<b>10</b>	<b>Weekly heating program</b> .....	<i>p. 11</i>
<b>5</b>	<b>Disabling thermoregulation</b> .....	<i>p. 8</i>	10.1	Heating program display .....	<i>p. 11</i>
<b>6</b>	<b>Configuration of boiler-related parameters (transparent parameters - TSP)</b> .....	<i>p. 8</i>	10.2	Change heating program.....	<i>p. 11</i>
<b>7</b>	<b>Operation mode selection</b> .....	<i>p. 8</i>	<b>11</b>	<b>Temporary change of the room setpoint</b> ....	<i>p. 12</i>
<b>8</b>	<b>Clock and temperature setting</b> .....	<i>p. 9</i>	<b>12</b>	<b>Fault signals</b> .....	<i>p. 12</i>
8.1	Clock setting .....	<i>p. 9</i>	12.1	Resettable faults.....	<i>p. 12</i>
8.2	Day room temperature setting .....	<i>p. 10</i>	12.2	Non resettable faults .....	<i>p. 12</i>
8.3	Night room temperature setting.....	<i>p. 10</i>	<b>13</b>	<b>Temperature values display</b> .....	<i>p. 13</i>
8.4	Heating temperature setting.....	<i>p. 10</i>	<b>14</b>	<b>Room antifreeze function</b> .....	<i>p. 13</i>
8.5	DHW temperature setting (not applicable).....	<i>p. 10</i>	<b>15</b>	<b>Error codes</b> .....	<i>p. 14</i>
8.6	Outdoor probe Kd value setting (not applicable).....	<i>p. 10</i>	<b>16</b>	<b>Restore default values</b> .....	<i>p. 14</i>
			<b>17</b>	<b>Complete reset</b> .....	<i>p. 14</i>
			<b>18</b>	<b>Technical specifications</b> .....	<i>p. 15</i>
			<b>19</b>	<b>Product fiche</b> .....	<i>p. 15</i>

# 1 HOW TO USE THIS INSTRUCTION MANUAL

This manual is intended for:

- ▶ **Installer:** provides information on the correct installation and configuration of the remote control.
- ▶ **User:** provides detailed information on the steps to be taken to customize the operation of the remote control.

Suggestions:

- ▶ When a numerical value is displayed flashing, you can change it by turning the  knob.
- ▶ The value modified by the  knob must be saved by pressing the  knob before the timeout, otherwise it will not be saved.

# 2 MAIN FEATURES


The remote control for Caldaria has been designed to ensure ideal temperature conditions at all times of the day, allowing any remote boiler setting to be made.

The remote control can be programmed with extreme ease: a large LCD display makes this operation easier, allowing you to check the settings you have made and to change them at any time.

The remote control is electrically connected to the boiler by means of two non-polarized conductors through which it receives the power supply necessary for its operation and carries out communication between the two devices.

Once installed it is ready to work with its standard stored program. The program can be modified according to the user's needs.

**Figure 2.1** Display and controls



- A  Operating status selection
- B  Clock and temperature setting
- C  Weekly program
- D  Change displayed value (turn) - Auto/manual selection (press)
- E  Alarm reset
- F  Temperature level selection (day/night)
- G  Temperatures display
- C + E  remote control parameters
- B + F  Boiler parameters

**Table 2.1** LCD symbols

Icon	Fixed	Flashing
	Current temperature display	Fault code display
	Time/temperature display	
	Current day of the week	Change the day of the week
	DHW enabled/ventilation only	DHW request in progress/ventilation only
	Heating enabled	Heating request in progress
	Manual operation	
	Burner on	
PROG	Heating program display	Change heating program
	Function inactive	Function inactive
	Current room setpoint display	Temporary change of the room setpoint
	Outdoor temperature display	
bar	System pressure display	
		Setting the time and the day of yhe week
		Day temperature setting
		Night temperature setting
	Heating temperature display	Heating temperature setting
	Function inactive	Function inactive
kd		Kd value setting
	Current temperature level = day	
	Current temperature level = night	
	Fault with no available reset attempts	Fault with available reset attempts
	Fault requiring technical service	
	Night level	
	Day level	

### 3 INSTALLATION

For installation of the remote control on the Caldaria Plus refer to the Installation, use and maintenance manual supplied with the Caldaria Plus.

The installation of the remote control must be carried out by qualified personnel.

#### How to install the remote control

1. Disconnect the boiler power supply.
2. Using a screwdriver, slide the remote control interface out of the rear fixing box, applying slight pressure on the two lower


tabs (Figure 3.1 p. 6).

3. Insert the two ends of the connection cable into the slot in the fixing box. Install the remote control, through the holes provided, directly on the wall or on a flush-mounting box, using the screws provided and taking care to follow the instructions "↑ UP" (Figure 3.2 p. 6).


It is recommended to position the remote control at about 1,5 m from the floor, away from draughts, direct exposure to sunlight, influence by direct heating sources (lamps, hot air flows of the appliance itself, etc..) and possibly on walls not bordering the outside, so as not to distort the measured temperature and therefore the

operation of the system. In this way, unwanted starts and stops of the system will be avoided and optimal comfort in the environment will be guaranteed.

**Figure 3.1** Accessing the remote control




**Figure 3.2** Installation of the remote control



4. Perform electrical connection to the terminal block (Figure 3.3 p. 6).


**i** The connection is not polarized.

**Figure 3.3** Electrical connection of the remote control



5. Fix the remote control to the fixing box by first inserting the upper part and pivoting on it until it is completely closed (Figure 3.4 p. 6).

**Figure 3.4** Closing the remote control



6. Power the boiler.
7. The installation is now complete. If the remote control has been correctly installed, it will be powered up and the connection message will appear on the LCD display for a few seconds (Figure 3.5 p. 6).

**Figure 3.5** Remote control connected



8. Once the connection has been established, the normal operating condition will be presented (Figure 3.6 p. 6).

**Figure 3.6** Operative remote control



## 4 CONFIGURATION OF THE OPERATING PARAMETERS

**i** This Paragraph is reserved exclusively for the authorised Robur Technical Assistance Centre.


**i** Incorrect configuration of the remote control may cause the system to malfunction.

This operation is used to configure the remote control in such a way that it is compatible with the boiler and the relative system to which it is connected.

### How to configure the operating parameters

1. Set the remote control to the OFF mode.
2. Press and hold down the  and  keys until PAr appears on the display.
3. To confirm access, press the  key. The display shows the parameter number instead of the time and the value associated with the parameter instead of the temperature. The parameter number flashes (Figure 4.1 p. 7).

**Figure 4.1** Selection of the parameter to be modified



4. Turn the  knob to select the parameter number to be displayed. The display shows the value associated with the parameter.
5. To change the value press the  knob: the value associated with the parameter starts flashing (Figure 4.2 p. 7).
6. Turn the  knob to change the displayed value.


**i** If no key is pressed for a period of 30 seconds, the change made is aborted and normal operation is restored.

7. Press the  key to save the value.
8. To exit the configuration mode, press .

**Table 4.1** Operating parameters

Parameter	Description	Value	Default
P00	Room temperature probe correction	-5 / +5 °C	0 °C
P01	Trip temperature for the room antifreeze function	0,1 / 10 °C 0,0 °C = OFF	5 °C
P02	Thermal differential OFF	0,0 / +1 °C	+ 0,3 °C
P03	Thermal differential ON	-1,0 / 0,1 °C	- 0,3 °C
P04	Thermoregulation type	0 - 4	0

**Figure 4.2** Changing the selected value (flashing)



The editable parameters are as follows:

- ▶ P00 Room temperature probe correction  
Value to add/subtract (-5.0 °C ÷ +5.0 °C) to the displayed room temperature to compensate for any errors.
- ▶ P01 Trip temperature for the room antifreeze function  
Trip temperature for the room antifreeze function (0,1 ÷ 10,0 °C).


**i** Setting parameter P01 to 0,0 disables the room antifreeze function.

- ▶ P02 Thermal differential (OFF)  
Value to be added to the set room setpoint that determines the end of the heating request.  
Example:  
 $T_{\text{setpoint}} = 20,0 \text{ °C}$   
 $P02 = 0,5 \text{ °C}$   
 $T_{\text{setpoint}} + P02 = 20,0 + 0,5 = 20,5 \text{ °C}$   
The heat demand ends when the  $T_{\text{room}}$  is greater than 20,5 °C.
- ▶ P03 Thermal differential (ON)  
Value to be subtracted from the set room setpoint that determines the start of the heating request.  
Example:  
 $T_{\text{setpoint}} = 20,0 \text{ °C}$   
 $P03 = 0,5 \text{ °C}$   
 $T_{\text{setpoint}} - P03 = 20,0 - 0,5 = 19,5 \text{ °C}$   
The heat demand starts when the  $T_{\text{room}}$  is less than 19,5 °C.
- ▶ P04 Thermoregulation type  
0 = On / Off  
1 = Modulating on room temperature probe  
2 = Modulating on outdoor temperature probe  
3 = Modulating on outdoor and room temperature probes  
4 = Disabled

## 5 DISABLING THERMOREGULATION

If the remote control is installed in an environment where the temperature is not to be controlled (technical room, office, other room than the boiler heated one), it is possible to disable the request for heat from the remote control itself. To do this, set parameter P04 = 4 (see Paragraph 4 p. 7). Instead of the room temperature, the display shows dIS (Figure 5.1 p. 8).

**Figure 5.1** Room temperature control from remote control: disabled



## 6 CONFIGURATION OF BOILER-RELATED PARAMETERS (TRANSPARENT PARAMETERS - TSP)

**This Paragraph is reserved exclusively for the authorised Robur Technical Assistance Centre.**

The remote control does not know the meaning of the items it displays but simply acts as a graphical interface to the boiler board.

The number of parameters to be set is transmitted via OpenTherm protocol.

### How to configure transparent parameters (TSP)

1. Set the remote control to the OFF mode.
2. Press and hold down the and keys for longer than 10 seconds. The display will show the flashing word TSP.
3. Release the and keys and, to enable the configuration, press the knob within 10 seconds.
4. The display shows the flashing number of the parameter instead of the time and the value associated with the

parameter instead of the temperature.

5. Turn the knob to select the parameter number to be displayed. The temperature display shows the values associated with the various parameters. Once the desired parameter has been selected, press the knob again: the parameter number stops flashing and the value associated with the parameter starts flashing to indicate that the value can be changed.
6. Turn the knob to change the displayed value. To save the value, press the knob again.

**i** If no key is pressed for a period of 10 seconds, the change made is aborted and normal operation is restored.

7. To exit the configuration mode before the timer expires, press the key.

## 7 OPERATION MODE SELECTION

**i** Depending on the boiler to which it is connected, some of the operating modes described may not be available.


The operating mode of the boiler is selected by pressing the key several times. The available operating modes are those shown in Table 7.1 p. 8.

**Table 7.1** Identification icon of the selected state

Selected status	Identification icon
OFF	OFF
summer	disabled
heating	disabled
heating only	

- OFF: all boiler operation requests are disabled (Figure 7.1 p. 9).

**Figure 7.1** Operating status OFF



- ▶ heating only: only operation in heating mode is enabled for the production of hot water to the internal modules. In this mode the boiler will produce hot water at the set temperature, modulating the heat output as the set-point temperature approaches.

## 8 CLOCK AND TEMPERATURE SETTING

The setting of the clock and of the temperature setpoints of the remote control and of the boiler is done by pressing the  key several times according to the menu shown in Table 8.1 p. 9.

**Table 8.1** Identification icon of the selected state

Selected status	Identification icon
clock	
day temperature	
night temperature	




The value of the item is displayed in the lower-left corner, instead of the time, together with the flashing of its identification icon. To end the setting operation, press the  key repeatedly until all the identification icons are off.

### 8.1 CLOCK SETTING

1. Press the  key: the time flashes (Figure 8.1 p. 9).


**Figure 8.1** Hour setting



2. Turn the  knob to set the desired value.


3. Press the  knob to confirm the value entered. The hour stops flashing and the minutes start flashing (Figure 8.2 p. 9).

**Figure 8.2** Minutes setting



4. Turn the  knob to set the desired value.
5. Press the  knob to confirm the value entered. The minutes stop flashing and the day of the week starts flashing (Figure 8.3 p. 9).

**Figure 8.3** Day setting




6. Turn the  knob to set the desired value.
7. Press the  knob to confirm the value entered. The day stops flashing and the  icon disappears.

## 8.2 DAY ROOM TEMPERATURE SETTING

1. Press the  key until the  icon starts flashing (Figure 8.4 p. 10).
2. Turn the  knob to set the desired value.


Figure 8.4 Day room temperature setting



## 8.4 HEATING TEMPERATURE SETTING

1. Press the  key until the  icon starts flashing (Figure 8.6 p. 10).
2. Turn the  knob to set the desired value.

Figure 8.6 Heating temperature setting




 This temperature value for models of the Caldaria family must be set to 80 °C. The change of this value will be operative on the boiler until the remote control is connected to it.

## 8.3 NIGHT ROOM TEMPERATURE SETTING

1. Press the  key until the  icon starts flashing (Figure 8.5 p. 10).
2. Turn the  knob to set the desired value.

Figure 8.5 Night room temperature setting



## 8.5 DHW TEMPERATURE SETTING (NOT APPLICABLE)

## 8.6 OUTDOOR PROBE KD VALUE SETTING (NOT APPLICABLE)

# 9 SETTING MANUAL/AUTOMATIC OPERATION

The remote control provides the possibility to manage the room temperature in two ways: manual or automatic.


- ▶ In manual mode, the user selects the desired room temperature, which will be maintained until a new change is made.
- ▶ In automatic mode, the room temperature setpoint is determined by the time and day corresponding to the weekly program set.

## 9.1 MANUAL OPERATION

1. Press the  key until the  icon appears. The display shows the set temperature value flashing (Figure 9.1 p. 11).
2. Turn the  knob to set the desired temperature.
3. After the 30-second time delay, the central display returns to the current temperature.

- The set temperature can be changed at any time by turning the  knob.
- You can display the set temperature by pressing the  key.

**Figure 9.1** Manual operation: setting the desired temperature



## 9.2 AUTOMATIC OPERATION

- Press the  key until the heating clock face is displayed.
- The  or  icon is lit to indicate which temperature level is currently set.

**Figure 9.2** Heating clock display and night temperature icon



## 10 WEEKLY HEATING PROGRAM

The room temperature can be set to two independent levels: day () and night () whose distribution throughout the day is managed by the weekly heating program.

The remote control contains a standard room temperature management program that can be viewed and freely modified by the user.

The display/modification mode of the heating program is activated by pressing the  key and is identified by the activation of the PROG icon at the top left of the display.

**Table 10.1** Identification icon of the heating program operation

Function	Identification icon
heating program display	PROG not flashing
change heating program	PROG flashing

 Once the changes have been made, press the  key again to exit the programming mode.

### 10.1 HEATING PROGRAM DISPLAY

- Press the  key.
- The display shows the PROG and  icons to indicate the first day of the week. The  /  and time switch icons are on  or off  at the day/night level associated with the displayed time (Figure 10.1 p. 11).
- Turn the  knob to scroll through the times of the day and switch between the days.

**Figure 10.1** Heating program selection



### 10.2 CHANGE HEATING PROGRAM

- Press the  key.
- The display shows the PROG and  icons to indicate the first day of the week. The  /  and time switch icons are on  or off  at the day/night level associated with the displayed time (Figure 10.1 p. 11).
- Press the  key to switch to the program editing mode: the PROG icon and the day of the week flash.
- Turn the  knob to select the desired day.
- Press the  knob to confirm the selected day and move to the time. The day of the week stops flashing and the time starts flashing.
- Turn the  knob to select the desired time.

7. Press the  key to change the day/night temperature level associated with the current time.
8. Turn the  knob until the time you want to keep the current level.

9. Press the  button to change the level and proceed in the same way for the other changes.
10. To change the day, repeat operations from step 3.
11. To exit the heating programming, press the  key.

## 11 TEMPORARY CHANGE OF THE ROOM SETPOINT

In the case of automatic operation, the room setpoint for the day () or night () can be temporarily raised or lowered. The change is valid until the next day/night change, after which it is lost.

1. Press the  key to display the set room temperature.
2. Turn the  knob to select the value. The  icon will flash for the duration of the change to indicate the setpoint change made (Figure 11.1 p. 12).
3. To deactivate the function before it expires, press the  key.

Figure 11.1 Temporary change of the room setpoint



## 12 FAULT SIGNALS

Any faults are displayed by the remote control with the Exx code flashing.



For more details about the fault refer to the Installation, use and maintenance manual of the specific Caldaria appliance used.

The faults can be of two types: resettable by the user and not resettable.


### 12.1 RESETTABLE FAULTS

These errors are identified by the flashing  icon and can be reset by pressing the  key.



If there are no more available attempts to reset the fault, the  icon is lit with no flashing. In this case, please contact the TAC.


Figure 12.1 Resettable fault



### 12.2 NON RESETTABLE FAULTS

These faults are identified by the  icon and cannot be reset by the user but require the intervention of the TAC. Also part of this error group is the code E06 (remote control room temperature probe fault) (Figure 12.2 p. 13).

**Figure 12.2** Non resettable fault



## 13 TEMPERATURE VALUES DISPLAY

By pressing the  key several times, the remote control is able to display the values of the items shown in Table 13.1 p. 13.


**Table 13.1** Identification icon of the selected item

Selected item	Identification icon
set room temperature	
DHW probe temperature*	
delivery probe temperature	
outdoor temperature*	

\* Not applicable to this model


- Set room temperature display: corresponds to the set temperature for the active temperature level (day/night/manual) (Figure 13.1 p. 13).

**Figure 13.1** Set room temperature display



- Delivery probe temperature display: corresponds to the temperature read by the delivery water probe in the boiler (Figure 13.2 p. 13).

**Figure 13.2** Delivery water probe temperature display



## 14 ROOM ANTIFREEZE FUNCTION

The remote control is equipped with the room antifreeze function (which can be excluded if necessary) which, regardless of the selected operating mode, controls the boiler activation when the temperature detected by the room probe is lower

than the value set in parameter P01, thus providing protection of the system from the danger of freezing.

## 15 ERROR CODES



For information about the error codes that may appear on the remote control display during operation, refer

to the Installation, use and maintenance manual of the specific Caldaria appliance used.

## 16 RESTORE DEFAULT VALUES

You can reset the settings of the remote control to their factory settings.

The default values of the temperatures are:

► Day temperature: 20 °C

► Night temperature: 16 °C

► Manual temperature: 20 °C

The factory-set weekly heating program is shown in Table 16.1 p. 14.

**Table 16.1** Weekly heating program


Days of the week	Night	Day
Monday - Friday	00.00 ÷ 06.00 08.00 ÷ 16.30 22.00 ÷ 00.00	06.00 ÷ 08.00 16.30 ÷ 22.00
Saturday - Sunday	00.00 ÷ 07.00 23.00 ÷ 00.00	07.00 ÷ 23.00



### How to reset default values

1. Set the remote control to the OFF mode.
2. Press and hold down the and keys for longer than 5 s.
3. The operation success will be confirmed by the word dEF on the display (Figure 13.2 p. 13).

**Figure 16.1** Restore default values



## 17 COMPLETE RESET


Faults or other technical reasons may require a total reset of the remote control.




### How to perform a complete reset

1. Using a screwdriver, slide the remote control interface out of the rear fixing box, applying slight pressure on the two lower tabs (Figure 17.1 p. 14).
2. Press button 1 (Figure 17.2 p. 15).
3. After a complete reset, the time and day of the week must be set again (Paragraph 8.1 p. 9).

**Figure 17.1** Complete reset



**Figure 17.2** Complete reset



## 18 TECHNICAL SPECIFICATIONS

**Table 18.1** Technical specifications

Description	Value
Power supply	via communication bus
Number of temperature levels	2 (day / night)
Day temperature setting range	5 ÷ 30 °C
Night temperature setting range	5 ÷ 30 °C
Manual temperature setting range	5 ÷ 30 °C
Setting range of the thermal differential (OFF)	0,0 ÷ 1,0 °C
Setting range of the thermal differential (ON)	-1,0 ÷ -0,1 °C
Correct operating range of the room temperature probe	-40 ÷ 50 °C
Temperature resolution	0,1 °C
Room temperature range for antifreeze function (0,0 °C = OFF)	0,1 ÷ 10,0 °C
Stop temperature for the room antifreeze function	set value + 0,6 °C
Heating time programming resolution	30 minutes
Maximum number of daily on/off	48
Number of standard heating programs	1
Number of standard DHW programs	1
Backup battery life in case of power failure	1 hour
Operating temperature range	0 ÷ 50 °C
Storage temperature	-10 ÷ 50 °C
Dimensions (WxHxD)	118x85x30 mm
Maximum boiler connection cable length	50 m
Boiler connection cables section	0,5 ÷ 1,5 mm <sup>2</sup>

## 19 PRODUCT FICHE

**Table 19.1** Commission delegated regulation (EU) n. 811/2013 - Temperature controls

Supplier	Model	Class of the temperature control	Contribution of the temperature control to seasonal space heating energy efficiency in %, rounded to one decimal place
Robur	OCDS006	V	0,03

## Robur mission

Robur is dedicated to dynamic progression in research, development and promotion of safe, environmentally-friendly, energy-efficiency products, through the commitment and caring of its employees and partners.



Robur S.p.A.  
advanced technologies  
for climate conditioning  
via Parigi 4/6  
24040 Verdellino/Zingonia (BG) Italy  
+39 035 888111 - F +39 035 884165  
[www.robur.it](http://www.robur.it) [robur@robur.it](mailto:robur@robur.it)

